




## CORNER SECTION

Corner sections are used only for internal corners of 90 degrees. Use two end sections for external corners and corners other than 90 degrees.



### BILL OF MATERIALS

Part No	Description	2.4m Qty	3.0m Qty
EF-220	Electro End Post 2.4m	1	
EF-230	Electro End Post 3.0m		1
EF-290	Corner Hooks	25	32
EF-270	End Insulator	50	64
EF-300	2.5mm High Tensile Wire	150 metres	192 metres
EF-410	Wire Clamp	25	32
EF-310	Permanent Wire Tensioner	25	32
EF-430	Warning Sign	0.66	0.66
CORNER SECTION PART NO		EF-800	EF-810

If the corner section is at the end of two zones, you will need extra EF-410 wire clamps.

